

**Precision Universal Tester** 

# Autograph AGS-X Series



## **Autograph**

# **AGS-X** Series

# PRACTICAL TESTING SOLUTIONS







10 kN 20 kN

50 kN

The Shimadzu Autograph AGS-X series provides superior performance and practical testing solutions for a wide array of applications. Offering high-level control and intuitive operation, the AGS-X series sets a new standard for strength evaluations while providing the utmost in safety considerations in a modern, stylish design.

The AGS-X comes standard with industry-leading TRAPEZIUM X data processing software. Offering comprehensive functions, TRAPEZIUM X offers an unparalleled level of operation. TRAPEZIUM LITE X, Shimadzu's entry-level data processing software, provides enhanced productivity and efficiency for quality control operations.






100 kN 300 kN

## **Convincing Cost Performance**

## New AGS-X Provides Practical, Affordable Testing Solutions

### **Easy Control of Stress and Strain**

Offers real-time auto tuning of control parameters, based on measured test force and strain data. Safely make comparisons to unknown sample data without the need for preliminary tests. In addition, the AUTOTUNING FUNCTION easily performs strain control, an ISO 6892-2009 requirement.




Load Cell

Precision

## Achieve an Accurate S-S Curve with High-Precision Load Cells

The wide, guaranteed load cell precision range of 1/500 to 1/1 improves testing efficiency and ensures that virtually all of your testing can be performed without switching the load cell or jig.

Furthermore, high-speed sampling of 1msec ensures no missed strength changes.



Load Cell

Precision

Range

High-Speed

Sampling

(1000 Hz

### **Improved Safety**

### SAFETY FUNCTION / ONE-TOUCH STROKE LIMIT


The safety function stops the testing machine if force changes exceed a certain level during specimen setting or return. In addition, setting stroke limiters is easy with one touch of the switch.

### SAFETY COVER

Controls scattering of the test specimen during testing. The interlock improves safety: operators can open and close it easily with the slide mechanism.

### **DUAL EMERGENCY-STOP SWITCHES**

Features emergency-stop switches on both sides (20 kN-300 kN frame).








## **Smarter Work Space**

New and enhanced functions support easier, more efficient testing



### (1) Safety Guard to Protect Against Flying Debris



A vertically sliding safety guard is available. Opens easily with one hand. When the safety guard is open, an interlock function disables testing and return movement.

### **② One-Touch Stroke Limiters**



Pinch and slide; release to lock. One-touch stroke limiters permit simple one-touch adjustment and firm locking of the crosshead stroke limit positions.

### (3) Load Cell



For the range of 1/500 to 1/1 of the load cell rating, a single load cell that quarantees test force accuracy to ±0.5% of the indicated value (for high-precision type) covers an extensive testing range. The load cell rated value is stored in the calibration cable and automatically recognized when the cable is connected.

### (4) Crosshead



Achieves a 1,600 mm/min testing speed and a 2,200 mm/min return speed (20 kN frame), significantly reducing the time required to conduct repetitive testing.

### (5) Common Joint for Both Tensile and Compression Tests (20-300 kN frame)





Adopts a single joint for both tension and compression tests.

This makes it easier to exchange jigs. In addition, the joint is set with a nut placed in the upper part of the loading cell, which allows for safe detachment of the joint on the table.

### 6 Built-in Main Operation Panel (for 10 kN frame)



Call up test methods from TRAPEZIUM LITE X to conduct testing. Naturally, AGS-X can be used as a standalone tester to test specimens using methods created with the tester itself.

### 7 Main Operation Panel







The main operation panel enables the development and storing of test conditions, allowing testing without having to connect to a PC. Perform various operations with the jog wheel, such as opening and shutting the button for automatic grips or the automatic extensometer. The main operational panel is movable, allowing convenient adjustment of the angle.

- The controller is needed separately for the automatic opening and shutting of jigs

### **8** Emergency Stop Button

Reliably cuts off power to the servo amplifier, instantaneously stopping crosshead movement in the event of an emergency.

### Multipurpose Tray (Desk-top frame)



Large space in front of the instrument. Perfect for placing jigs, arranging specimens, or taking notes.

### Jog Controller (option for 10 kN frame)



Allows hand-held control of the crosshead position. The jog dial makes fine positioning a breeze, particularly when setting the start position for bending and compression tests.

## **Quest for Convenience**




### Cutting-Edge Software Meets Your Materials Development and Quality Control Needs





NEW

### **Quickly Obtained Data**



### **1** Test Method & Situation Panel

Confirm testing conditions and the situation from the main window.

### **② Advanced Navigation System with a Learning Function**

The Navigation Bar shows only the functions required for selected situations. In addition, the "Learning Function" records user actions for each situation and adds frequently-used functions as navigation buttons. This improves work efficiency by matching functions to a user's operational style.

### **3 Multiple Graph Function**

Enables displaying up to four graphs. The graph can set two axes, respectively. In addition, a maximum of 50 graphs can be overlaid and point picking allows acquiring the value of a random point. This provides for a more detailed examination.

### **4** Real-time Data Display Panel

Displays the test force, stroke (strain), extensometer or strain gauge value and other input values, enabling one-window monitoring.

In addition, the random calculation value can be display simultaneously for smooth confirmation of data.

### **5** Quick Panel

Quickly enter the speed, dimension, and report information from the main window.

### **6** Result Panel


In addition to re-testing and extra lot tests, this panel allows changing a variety of settings before and after testing. Specimens can be inserted in any position or added to only a specific batch, and the specimen order can be changed after completing the test.

### **① Checkbox to Select Display Curve**

### **Intuitive Machine Operation**

### Visual wizard guidance ensures trouble-free entry of method settings

- Enter complicated method settings using the Method Wizard, which provides an overview of the entire process.
- Setting entry guidance, linked to online help, is available in each window.
- Easy-to-understand illustrations are used in the [Tension], [Specimen], and [Data Processing] windows, greatly simplifying the entry of settings.



Displays illustrations for each specimen shape. A single glance shows which dimensions should be entered.

In addition to manual input, dimensions can be set via [Excel batch reading] or [Automatic input via calipers].

Enter additional, non-dimensional information for each specimen.


Prepare data processing items in advance. Simply press buttons on the figure to select settings.

Illustrations change according to the test mode and specimen material.

Create random calculation formula using a data processing item or specimen size.

An example of selected plastic (Beside this, rubber and metal are available,)

### Perform high-efficiency, continuous testing utilizing fast data searches and one-touch method selection



### **Generate Detailed Reports**

## Richly expressive report creation includes free positioning of report elements

Report Designer allows flexible layouts. Create reports that include data, charts, photographs, and logs. Freely change the layout and element size, and use detailed settings for each element's font, color, and ruled line.

Reports can be output in PDF, Microsoft Word, Excel, HTML formats.

After exporting, use your everyday software to customize the report.


### **Conventional Process Control Function**



Utilize daily test records to create an XBar-R control chart using data that has been extracted for a certain period.

Daily test result statistics are available in various units, including date, specimen, batch, etc. The statistical result is displayed on the screen

It is possible to print them by adding the text and to output it as a PDF file.



### **Choose from Four Software Components to Fit Your Specific Application**

When multiple software components are purchased, easily switch between modes at a single touch, without starting up separate software.


### Single Software

Performs general single-direction testing. Examples include tensile, compression, bending and peeling tests.



### Cycle Software

Similar to endurance testing, this software is used for testing where force is repeatedly applied and then released.



### **Control Software**

Create any testing machine operation pattern. Perform foam rubber compression and holding cycle tests.



### Texture Software

Measures the features (texture) of foods and pharmaceuticals. Produce special data processing results, including mastication, jelly strength and adhesion.



## **Simple Software Improves Productivity**








# Improves Productivity and Efficiency of Quality Control

Performs general single-direction testing. Examples include tensile, compression, bending and peeling tests.



### Simple Screen Layout Few buttons ensure easily navigated operations One-touch test method selection

### Supports Industry Standards Recording convenient test method files enables instant testing

Includes test method files for rubbers, plastics, and films that comply with JIS/ISO/ASTM standards. The terminology and data processing items specified in the test standard are pre-registered in the respective test method file to permit smooth testing in compliance with the standards.



### "Quick Method List" Makes Testing Easy No mouse or keyboard required

Register often-used test methods to the Quick Method List to start testing instantly. The registered test methods can be directly selected or edited at the AGS-X tester, making testing easy even for users who find using a PC troublesome.



### Macros Enhance Work Efficiency Just set up the test and start testing. All tedious operations have been automated.

The sequence of operations frequently conducted after testing can be fully automated. Functions for coordinating with the AGS-X permit saving of test data and report generation and printing without touching a PC.








**Examples of Macros** 

## Statistical Process Control Functions Effectively utilize daily test results.

Extract and compile test results over a fixed period to create histograms and XBar-R control charts. Compile statistics on daily test results by date, specimen, or batch, and display the results on screen. Add text to statistical information for printing or output to a PDF file.



## **Accessories**

## Experience the range of possibilities available with this full-featured system



AGS-300kNX + 300kN Non-Shift Wedge Type Grips



AGS-10kNX + 1kN Parallel Tightening Grips + SES-1000 Extensometer for soft specimens

Used to grip the sample, a wide variety is available to accommodate different specimen types and test force amounts.

Plastics Rubber Textiles Cloth Paper Film

Non-Shift Wedge Type Grips <mwg></mwg>					
Grip		Upper grip			
capacity	Grip face	Clearance (mm)	Grip width (mm)	Grip length (mm)	weight (kg)
300 kN		0 to 8.5	50	75	33
250 kN		0 to 8.5	50	75	33
100 kN	File teeth for	0 to 7	40	55	10
50 kN	flat specimens	0 to 7	40	55	9.5
20 kN		0 to 7	25	55	3.6
5 kN		0 to 7	25	55	3.6

Grip	External dimensions (mm)		Grip width	Clearance	Upper grip
capacity	w	L (upper/lower)	(mm)	(mm)	weight (kg)
10 kN	154	268.5 / 278.5	60	0 to 10	_
5 kN	154	224 / 235	60	0 to 6	5.7
1 kN	102	163 / 174	50	0 to 6	1.7
50 N	64	118 / 135	35	0 to 6	0.4



Non-Shift Wedge Type Grips



**Pneumatic Flat Grips** 

<sup>\*1</sup> Grips with foot-valve units and crosshead - linked control functions are also available.
\*2 Grips can be opened and closed via the Smart Controller when using the crosshead-linked control kit.

### Screw-Type Flat Grips <SCG>



Grip		Upper grip weight			
capacity	Grip face	Clearance (mm)	Grip width (mm)	Grip length (mm)	(kg)
5 kN	File teeth	0 to 16	60	50	2
1 kN	riie teetii	0 to 15	50	30	0.7
50 N	Flat	0 to 14	35	25	0.3

### Parallel Tightening Grips

Grip	Size (mm)		Grip face width and length	Face clearance	Upper grip weight
capacity	w	L	(mm)	(mm)	(kg)
300 kN	574	440	60, 90	0 to 60	170
100 kN	446	310	40, 70	0 to 40	90



<sup>\*2</sup> Optional compression jigs and bending jigs that can be connected directly to the grips are also available.



Screw-Type Flat Grips



Parallel Tightening Grips

### ■ Compression plate Plastics Metals Rubber Lumber Cement












Used to compress the specimen, several type are available to accommodate different specimens and test force amounts.

### Fixed Type

Maximum capacity	Upper plate dimensions (mm) diameter by thickness	Upper plate mass (kg)	Operational temperature (°C)
	ø100 × 25	1.6	
250 kN	ø50 × 25	0.5	0 to 40
	ø200 × 40	6.3	

### Spherical Seat Type

Maximum capacity	Upper plate dimensions (mm)	Upper plate mass (kg)	Operational temperature (°C)
250 kN	ø100	3.8	0 to 40



Spherical seat-type compression plates provide contact flexibility for uniform load application. \* Select the kit number that corresponds to the load cell used.



**Fixed-Type Compression Plates** 



Spherical Seat-Type **Compression Plates** 





Simply attach the bending test jig kit to the main unit to perform bending testing.

Max. test force	Punch tip radius × width (mm)	Support tip radius × width (mm)	Support spacing (mm)	Operational temperature (°C)	Applicable test standards	
10 kN	R5 × 34	R2 × 34	20 to 200		JIS K6911, JIS K6902*1, JIS C6481*2, JIS K7171, ISO 178, Specimens with thickness of 3 mm or less	
TORIN		R5 × 34		0 to 40	JIS K7171, ISO 178, Specimens with thickness above 3 mm	
	R1/8" × 72	R1/8" × 110	0.8 to 8"		ASTM D790 (Test method 1)	
100 kN	R5 × 72	R2 × 110	50 to 500	50 to 500		JIS K6911, JIS K6902*1, JIS C6481*2, JIS K7171, ISO 178, Specimens with thickness of 3 mm or less
100 kN		R5 × 110			JIS K7171, ISO 178, Specimens with thickness above 3 mm	
	R1/8" × 72	R1/8" × 110	2 to 20"		ASTM D790 (Test method 1*3)	

<sup>\*1</sup> Corresponds to bending strength. Compatible with support spacing from 20 mm to 200 mm. \*2 Corresponds to bending strength.

\*3 Compatible with support spacing from 2 inches to 20 inches. Requires an adaptor when the SIE or SES extensometer is used.

### Deflection Measuring Device for Three-point Bending Test



Applicable to the ISO 178 three-point bending test, it is possible to use this device with plastic three-point bending jigs.



Three-point Bending Test Jig for Plastics



Deflection Measuring Device with Three-point **Bending Jig for Plastics** 

### ■ Precise Measurement of Displacement




AGS-10kNXD + Pneumatic Flat Grips + TRViewX Non-Contact Digital Video Extensometer

### Automatic Extensometer SIE Series

Automatic gauge position detection, gauge length setting, and arm clamping and unclamping of specimen.







Class 0.5

Extensometer

Single camera

(TRViewX S Series)

Plastics Metal Metal Foil Rubber Film

TRViewX Non-Contact Digital Video

Conducts accurate gauge length elongation measurements on specimens, based on CCD camera images, over an extensive range.

Easily and accurately measures large elongation amounts. 1000 mm Maximum Movement Distance, ±0.2% Relative Elongation Measurement Precision.



Camera Field-of-View (GL + elongation)

55 mm\*1

120 mm\*1

240 mm\*<sup>1</sup>

500 mm

800 mm

Camera Field-of-View (GL + elongation)

Class 0.5

### Strain Gauge One-touch Extensometer SSG-H Series

Lightweight, compact extensometer that can be attached or removed by a simple, one-touch operation.

\* Requires external amplifier (option).

Measurement Device

during compression tests.



### **Differential Transformer Type Extensometers DT Series**

Class 1

Applicable to the elongation measurement of metal.

Maximum diameter, thickness 45 mm Compliant with Strain Rate Control Test Methods ISO 6892

Compression Plate Displacement

Measures displacement of compression plates











Measures changes in specimen width.



Camera 1: 120 mm \* Camera 2: 500 mm TRViewX500D Double camera \*2 (TRViewX D Series) Camera 1: 120 mm \*1 Camera 2: 800 mm TRViewX800D

\*1 Elongation accuracy at normal temperatures is ISO Class 0.5 compliant.

Model

TRViewX55S

TRViewX120S

TRViewX240S

TRViewX500S

TRViewX800S

Model

\*2 With the double camera model, camera 1 takes measurements with a field of view up to 120 mm, beyond which the system switches to camera 2. Select models 500D/800D if you require a wide field of view (500 mm/800 mm) and Class 0.5 compliance up to a 120 mm







### ■ Testing in Controlled Environments



AGS-10kNXD + Screw Type Flat Grips + Compact Thermostatic Chamber TCE series

Temperature Range

−70 °C to +280 °C

## Compact Thermostatic Chamber TCE Series

Enables testing across a temperature range of  $-70\,^{\circ}\text{C}$  to  $+280\,^{\circ}\text{C}$ .  $+150\,\text{mm}$  and  $+250\,\text{mm}$  extension models are also avilable.



Temperature Range +20 °C to 60 °C (-40 °C to 250 °C with no humidity control)

Humidity Range

40% to 95%

### Refrigerator Type Environmental Temperature and Humidity Chamber

Optimal chamber for testing materials with mechanical properties sensitive to temperature and humidity effects, such as fibers, paper, or films.

Temperature regulation: Automatic control by heater and refrigerator.



Temperature Range

–70 °C to +280 °C

## Gas Jet Type Thermostatic Chamber TCL, TCH Series

Liquid nitrogen or carbon dioxide is injected to lower the temperature. Offers colder testing environments than the refrigerator type. Heating: Heater; Cooling: Liquid nitrogen or CO2 injection



Temperature Range +300 °C +900 °C +300 °C +1100 °C

### 900 °C / 1100 °C High-Temperature Tensile Test Device

This test device is for tensile, bending and compression testing of steel, heat-resistant materials and ceramics under high temperature conditions.

\* High temperature device can be used with floor type model (100 kN/300 kN).



Class 1

### High Precision Digital Extensometer for High-Temperature Tensile Test Device

This device complies with ISO Class 1 and ASTM B2 Class and is also applicable to the strain control for tensile testing of metals.



### ■ Jigs for Specific Testing and Specimen Shapes

### Pneumatic Capstan Grips for Yarn

These grips grip a yarn or cord specimen from the capstan (winch). The pneumatic operation allows application of an initial test force.



JIS Z0237

JIS Z1528

### Adhesive Tape Peeling Test Device

The sample table slides in synchronization with the upper grip movement to maintain a 90° peeling angle. Peeling test jig compliant with JIS Z0237 and JIS Z1528.



ASTM 1894

JIS K7312

Plastics Film

ASTM D412

### Friction Modulus Test Device

For measurements of the coefficient of sliding friction between identical plastics or films or between different materials across the continuous range from static friction to dynamic friction. Two versions: compliant with JIS K7312 / ASTM 1894 and compliant with JIS K7125 / ISO 8295



### 1 kN Roller Grips

The O-ring is hooked onto rollers, which rotate during tensile testing. Conforms to JIS K6251, JIS K7312, ISO 37, and ASTM D412 test standards.





Jigs for CFRP Testing Standards

### ASTM D6484 / D6484M

### Open-Hole Compression Strength **Testing on Polymer Matrix** Composite Laminate

ASTM D6484 is a typical method used to determine the compressive strength of CFRP open-hole samples.



### ASTM D7137 / D7137M

### Testing the Compressive Residual Strength Characteristics of a Damaged Polymer Matrix Composite Plate

The testing is performed on rectangular samples made of composite materials that have already been subjected to impact testing. The sample is mounted on the jig and subjected to compression loads.



### In-Plane Shear Testing Double-V-Notched Sample Shearing

The in-plane shear strength, in-plane shear fracture strain, and in-plane shear elastic modulus of carbon-fiber-reinforced plastics can be determined by the losipescu test, which is an in-plane shear test on double-V-notched samples.



### ASTM D7078 / D7078M

### V-Notched Rail Shear Testing and **Evaluation of Composites**

This testing applies shear forces to mounted samples with 90-degree V-notches at the top and hottom



## **Options**

### ■ Optional Frames for AGS-X Series

Capacity	10 kN	20 kN	50 kN	100 kN	250 kN/300 kN
Reinforced Yoke Specification	/	-	=	=	=
+250 mm Extended Column	/	=	=	1	-
+500 mm Extended Column	/	1	✓	-	_

### **Reinforced Yoke Options**

Permits tensile testing in the download direction. (Only for 10 kN model)



### **Extended Column Options**

For testing with a longer test stroke.



### Options for AGS-10kNX Frame



Jog Controller

The jog dial allows manual positioning of the crosshead.



### Power Cable

EU specification (VDE standard) Chinese specification (GB standard) Japanese, N. American specification (UL, CSA, PSE standards) supplied as standard.

### ■ Options for AGS-X Series



Control I/O Box

Expands the number of control I/O ports to four. Multiple options can be simultaneously connected to the control I/O ports.



### Sensor I/O Box

Expands the number of sensor I/O ports to two. Multiple options can be simultaneously connected to the sensor I/O ports. BNC cables can be connected to the analog I/O ports (2 ports each).

Other options are also available. For details, refer to the separate catalog (Shimadzu Autograph Optional Accessories).

## **AGS-X Series Specifications**







AGS-10kNX				AGS-20kNX		
	Ma	odel	Table	e-top		
	IVIC	odei	AGS-10kNX	AGS-20kN		
	Max. Load	d Capacity	10 kN	20 kN		
Lineup of Mo	odels Differi	ing by Load Cell Capacity	1 N / 2 N / 5 N / 10 N / 20 N / 50 N 100 N / 500 N / 1 kN / 5 kN / 10 kN	20 kN		
		High-Precision Type	Within ±0.5% indicated test force (at 1/500 to 1/1 load cell rating)			
	A	(1/500, ±0.5%)	Conforms to EN 10002-2 Grade 0.5, ISO 7500- JIS B7721 C			
Force Measurement	Accuracy	Standard-Precision Type	Within ±1% indi (at 1/500 to 1/1			
		(1/500, ±1%)	Conforms to EN 10002-2 Grade 1, ISO 7500 JIS B7721			
		Calibration	Automatic test force calibration: select tensi	ile, compression, or tensile and compression		
Crosshe	aad	Speed Range	0.001 to 1000 mm/min (stepless)	0.001 to 1600 mm/min (stepless)		
C1033110	-uu	Max. Return Speed	1500 mm/min	2200 mm/min		
Cro	osshead Spe	ed Accuracy *2	±0.	1%		
Crosshead	d Speed and	l Permitted Test Force	To load cell capacity acr	ross entire speed range		
Cr		Table Distance stroke) *3	1200 mm (760 mm, MWG)	1250 mm (765 mm, MWG)		
	Effective 7	Test Width	425	mm		
Crosshe	and .	Measurement Method	Optical o	Optical encoder		
Position De		Display Method	Digital display (display resolution: 0.001 mm)			
		Positional Accuracy	±0.1% indicated value or ±0.01 mm, whichever is larger			
		ture Rate	1000 Hz max. * <sup>4</sup>			
	Test Met	hod Files	40 files (PC link: 20 files, standalone controller: 20 files)			
	Standard Functions		Automatic reading of load cell characteristic values     Test force display, stress display, stroke display,     position display     External analog output (2 channels)     External analog input (2 channels) *4     External digital input (2 channels) *4     Analog recorder (option) output     Dataletty (option) output *5	<ul> <li>Automatic test force / stress control (Autotuning)</li> <li>Automatic strain control (Autotuning) *4</li> <li>Test force auto-zeroing</li> <li>Test force auto-calibration</li> <li>Break detection, auto-return</li> <li>Load cell overload detection</li> <li>Touch-load detection function</li> </ul>		
	Acces	sories	Load cell (with CAL cable), Power cable (2.5 m), turning rod, cable clamps, instruction manual	Load Cell (with CAL cable), Power cable (5 m), turning rod, cable clamps, instruction manual		
Dimensions		nsions	*Special-purpose desk (option) (Unit: mm)  *950  *950  *950  *500	*Special-purpose desk (option) (Unit: mm)  *1200  *1200  Front  W718 × D641 × H1633 mm		
Weight		ight	85 kg	235 kg		
	weight		Single phase 100/120/220/240 V AC (switching type) 50/60 Hz 1.2 kVA	Single phase AC 200–230 50/60 Hz 4.0 kVA		
	Power Rec	quirements	Supply voltage fluctuations within $\pm 10\%$ of the set value. D-class (100 $\Omega$ max.) grounding resistance.			
	Operating E	Environment	Temperature: 5 °C to 40 °C; Humidity: 20% to 80% (no condensation) Floor vibrations: frequency 10 Hz max., amplitude 5 µm max.			

- \*1 Official certification after installation is recommended to comply with EN 10002-2, ISO 7500-1, ASTM E4 standards, and JIS B7721.

  \*2 Crosshead speed accuracy is calculated from the crosshead travel within a prescribed time at a constant speed between 0.5 mm/minute and 500 mm/minute.

  \*3 The tensile stroke is the effective stroke when SCG (screw-type flat grips) or MWG (non-shift wedge-type grips) are mounted.

  \*4 TRAPEZIUM X or TRAPEZIUM LITE X is needed for these functions. Moreover, when automatic test force/stress control (auto tuning) and the automatic strain control (auto tuning) are used, the sampling speed becomes 10 msec.







AGS-100kNX



AGS-300kNX

Table Top Type	Floor Type			
AGS-50kNX	AGS-100kNX	AGS-300kNX		
50 kN	100 kN	300 kN		
50 kN	100 kN	300 kN		
Within ±0.5% indicated test force	Within ±0.5% indicated test force (at 1/250 to 1/1 load cell rating)			

Conforms to EN 10002-2 Grade 0.5, ISO 7500-1 Class 0.5, BS 1610 Class 0.5, ASTM E4, and JIS B7721 Class 0.5.\*1

Within ±1% indicated test force (at 1/500 to 1/1 load cell rating)

Conforms to EN 10002-2 Grado 1 ISO 7500-1 Class 1 RS 1610 Class 1 ASTM E4 and IIS R7721 Class 1 \*1


Conforms to EN 10002-2	Grade 1, ISO 7500-1 Class 1, BS 1610 Class 1, AS	STM E4, and JIS B7/21 Class 1. *'		
Automatic test f	orce calibration: select tensile, compression, or	tensile and compression		
0.001 to 800 r	nm/min (stepless)	0.001 to 500 mm/min (stepless)		
1100	mm/min	550 mm/min		
	±0.1%			
To load cell capacity ac	0.001–200 kN: 0.001–500 mm/min (entire speed range) 200–300 kN: 0.001–400 mm/min			
1210 mm	1255 mm	1475 mm		
(745 mm, MWG)	(745 mm, MWG)	(635 mm, MWG)		
425 mm	600 mm			
Optical encoder				
Digital display (display resolution: 0.001 mm)				
$\pm 0.1\%$ indicated value or $\pm 0.01$ mm, whichever is larger				

### 1000 Hz max. \*4 40 files (PC link: 20 files, standalone controller: 20 files)

- Automatic reading of load cell characteristic values
- Test force display, stress display, stroke display, position display
- External analog output (2 channels)
- External analog input (2 channels) \*4 External digital input (2 channels) \*4
- Analog recorder (option) output
   Dataletty (option) output \*5

- Automatic test force / stress control (Autotuning)
- Automatic strain control (Autotuning) \*
- Test force auto-zeroing
- Test force auto-calibration
- Break detection, auto-return
- · Load cell overload detection
- Touch-load detection function


### Load Cell (with CAL cable), Power cable (5 m), turning rod, cable clamps, instruction manual



W718 × D641 × H1633 mm

(Unit: mm) 945 Front

W945 × D725 × H2164 mm 525 kg



W945 × D725 × H2414 mm 675 kg

260 kg Single phase AC 200–230 V 50/60 Hz 4.0 kVA

400 V model: Three phases AC 380-440 V 50/60 Hz 4.5 kVA 200 V model: Three phases AC 200–230 V 50/60 Hz 6.5 kVA

400 V model: Three phases AC 380–440 V 50/60 Hz 5.5 kVA 200 V model: Three phases AC 200–230 V 50/60 Hz 7.5 kVA

Supply voltage fluctuations within ±10% of the set value.

D-class (100  $\Omega$  max.) grounding resistance.

400 V model: C-class (10  $\Omega$  max.) grounding resistance. 200 V model: D-class (100  $\Omega$  max.) grounding resistance.

Temperature: 5 °C to 40 °C; Humidity: 20% to 80% (no condensation) Floor vibrations: frequency 10 Hz max., amplitude 5 µm max.

- \*5 Dataletty (option) and TRAPEZIUM X / TRAPEZIUM LITE X can not be used together.

  \* Values stated in this catalog are based on measurements conducted according to separately defined inspection standards.
- \* Windows 7/ Windows Vista/ Windows XP is a registered trademark in the United States and other countries of Microsoft Corporation.

## **Testing and Evaluation Machines**

**Precision Universal Tester** AG-X plus series



Small Table-Top Tester **EZ Test** 



**Universal Testing Machines UH-X/FX** series



Micro Hardness Tester **HMV-G** series



Dynamic Ultra Micro Hardness Tester **DUH-211/211S** 



Electromagnetic Force Fatigue / Endurance Testing System Servopulser EMT series





**Shimadzu Corporation** www.shimadzu.com/an/

For Research Use Only. Not for use in diagnostic procedures.
This publication may contain references to products that are not available in your country. Please contact us to check the availability of these

products in your country. Prease contact us to check the availability of these products in your country. Company names, products/service names and logos used in this publication are trademarks and trade names of Shimadzu Corporation, its subsidiaries or its affiliates, whether or not they are used with trademark symbol "TM" or "®". Third-party trademarks and trade names may be used in this publication to refer to either the entities or their products/services, whether or not they are used with trademark symbol "TM" or "®". Shimadzu disclaims any proprietary interest in trademarks and trade names other than its own.

The contents of this publication are provided to you "as is" without warranty of any kind, and are subject to change without notice. Shimadzu does not assume any responsibility or liability for any damage, whether direct or indirect, relating to the use of this publication.